

KERAMA

HARVEST CLADDING

INSTALLATION GUIDE








KERAMA

TABLE OF CONTENTS



1 - PROFILES & INSTALLATION OVERVIEW 03

- Product Profile
- Screw Installation
- Click System Installation

2 - 10 INSTALLATION STEPS 05

- Storage Information
- Tools
- Rear construction
- Customisation
- Ventilation Space
- Orientation of the Boards
- Expansion
- Fastening
- Finishing
- Maintenance


3 - HORIZONTAL INSTALLATION 08

- General Overview
- Cortex Finish
- Kerama Finishing Boards and Corners
- Aluminium Corner Line
- Symmetrical Outer Corner profile
- Internal Angle
- Assembly Starter Board
- Replacing Boards
- Tacker Fastener
- EPDM foil


IMPORTANT: THE IMAGES IN THIS INSTALLATION GUIDE ARE INTENDED TO PROVIDE A GENERAL IDEA OF THE PRODUCT AND ARE FOR ILLUSTRATIVE PURPOSES ONLY.

View the warranty information on our website.

MEASUREMENTS



WORKING WIDTH WITH SCREWS



WORKING WIDTH WITH CLICK SYSTEM

(Keraloc & Grad)

> BOARD 140 MM - 123 mm

> BOARD 200 MM - 183 mm


> BOARD 70 MM - 53 mm

ITEMS



KERAMA HARVEST BOARDS

70x20x3000mm
140x20x3000mm
200x20x3000 mm




KERAMA FINISHING BOARDS & CORNERS

Inner & outer corner 38x20x3000mm
Finishing board 140x25x4880mm
Finishing board 176x25x4880 mm



STAINLESS STEEL SCREWS

3.5x35mm
3.5x40mm



ALUMINUM CORNER LINES & PROFILES

Corner Line
Symmetrical Outer Corner
Profile Inner Corner



GRAD® CLIP



ALUMINUM START & VENTILATION PROFILES

Ventilation profile
Start profile



GRAD RAIL

Different sizes available



EPDM RUBBER




KERALOC® CLICKCLIP




KERALOC® STEEL PROFILE

35x25x4000mm
35x25x2395mm

10 IMPORTANT STEPS





1 STORAGE

- It is essential that the boards are stored horizontally on a flat surface.
- Ensure that the material at the work site or construction site is covered with a **white, ventilated rubbe**r to protect it from direct sunlight.
- Always remove the boards from under the protective covering and install them **immediately**. If the boards warm up in the sun before installation, they may shrink as they cool, which can cause permanent gaps.
- Do not install the boards **in extreme temperatures**, such as above 30°C or in frost.

2 TOOLS

- Mitre saw
- Spirit level / laser
- Electric screwdriver / tacker



Figure 2




Figure 3

3 REAR STRUCTURE

- A double batten (cross-lath installation) is **required** when installing the boards **vertically**. For horizontal installation, a single batten is sufficient.
- Install the slats with a center-to-center distance of **400 to 450mm.**
- The ends of two boards can be attached to the same batten, provided there is sufficient space. (When attaching the ends, allow a **minimum spacing of 15 mm** for the screws.)




Figure 4

4 CUSTOMISATION

- Each board must be cut to size before installation. Always cut with the visible side of the plank facing down, see **figure 5**.
- Sawing must be carried out accurately in order to achieve neat end joints.




Figure 5




Figure 6

5 VENTILATION SPACE

- It is important that the material can ventilate properly, so ensure there is sufficient space for air to circulate freely, see figure 6.
- Install 150 mm above ground level, and leave a 20mm distance between boards, sheet metal, walls etc.
- The ventilation space (batten thickness) must be at least 28 mm.
- Always ensure there is a clear ventilation opening at the bottom (inlet) and top (outlet) of the facade. This opening must be at least 15 mm.



Figure 7

6 ORIENTATION OF THE BOARDS

- **Horizontal installation:** make sure that the tongue always points upwards and the groove where the lip is slid into is facing downwards, see **figure 7.**
- **Vertical installation:** a double framework (cross-batten processing) is mandatory

No expansion space



Figure 8

7 EXPANSION

- Under normal circumstances the planks are mounted cold against each other, without any expansion space at the end edges **(Figure 8).**
- **Important installation conditions**
- It is strongly discouraged to install the boards at temperatures below **0°C** and above **30°C.**
- Remove the boards from the pallet and **install them as quickly as possible** to prevent them from heating up in the sun.
- Do not install boards that have already been heated by **direct sunlight.**

8 FASTENING

1. Screws

- Screw the board in place to prevent cracking. Don't overtighten the screw after pre-drilling.




Figure 10

Degree

2.Click System

- Align the groove of the Harvest board with the clips on the Grad rail. Press the plank firmly until it clicks into place. Check that the board is securely fastened along its entire length.



Figure 11

9 FINISHING

- We recommend our finishing profiles with wood grain (Kerama) or aluminium profiles.
- All options are described in this manual.


10 MAINTENANCE

Kerama boards guarantee UV resistance without visible discoloration. The material may become dirty over time. Cleaning can be done with water and a mild detergent; careful use of a pressure washer is also possible.

GENERAL OVERVIEW



CORTEX FINISH




The Cortex finish is designed for virtually invisible fastening of the cladding boards. The screw holes are covered with a Cortex cap that features a matching wood grain texture. This results in a sleek finish without visible fastening points.

For even more refined detailing, the tongue of the board can be sawn off.

KERAMA FINISHING BOARD



Kerama Finishing Board



Kerama Finishing Board

FINISHING PROFILES FOR A PERFECT DETAIL

Harvest cladding's finishing profiles provide a perfect, detailed finish to your exterior cladding. They offer a versatile solution for clean corners and seamless window and door frames. Available in various shapes for a high-quality result.

The Cortex system is also suitable for invisible mounting of finishing boards and corners.







KERAMA INNER AND OUTER CORNERS





INNER AND OUTER CORNERS

Our Kerama finishing profiles ensure a perfect, detailed finish to your facade. They offer a versatile solution for clean corners and seamless window and door frames. Available in various shapes for a high-quality result that suits any style.

INNER AND OUTER CORNERS

WITH INNER CORNER PROFILE






WITHOUT INNER CORNER









ALUMINIUM CORNER LINE













CORNER LINE

The aluminum angle line is suitable for almost all 90 degree applications. This aluminium corner profile is also called a corner strip, corner skirting board or L-profile.

INSTALLING THE STARTING BOARD


WITH VENTILATION PROFILE





This ventilation profile is specially designed to ventilate facades and roofs, while at the same time preventing animals such as birds, rodents and large insects from damaging the structure.

VISIBLY SCREWED



OR

MET CORTEX




Using our cortex caps, the first (lower) ‘Lines’ can be invisibly attached to the bottom side.

REPLACING BOARDS


WITH SCREW



Step 1




Step 2




Step 3


WITH GRAD



Step 1



Step 2 (USE: Grad® : DISMANTLING KEYS)



Step 3


TACKER FASTENING




The specially designed nosepiece is essential for the correct positioning of the tacker, so that you always attach in the right place.




Using a tacker for our cladding significantly speeds up installation compared to using screws. The consistent hammering force ensures consistent nail depth, which is essential for a perfect and professional finish. Moreover, the lightweight design and rubber nose piece make working comfortable while preventing damage to the cladding panels.





EPDM RUBBER



Using EPDM film is a crucial step for a durable and maintenance-free application. This sheeting provides the necessary protection for the most vulnerable parts of the structure.

- Recommended for long-lasting results. The rubber forms a **waterproof and windproof** barrier.
- Protects the wooden support structure. This is essential when using less intensively treated wood types. The EPDM film reduces the risk of moisture corroding the wood.
- Perfect for uneven surfaces. Thanks to its high flexibility, the film effortlessly absorbs irregularities in the wooden frame and ensures a seamless, tight seal.



KERAMA

KERAMA GROUP B.V.

Braillestraat 10
2652 XV,
Berkel en
Rodenrijs
The Netherlands

info@keramagroup.com

www.keramagroup.com